


HT-DDD100

Digital Dual Driver Governor

Instruction manual



Doc. No.: HT-DDD100_MN_DE_02.12.2015

Version: 1.2

Edition: 02.12.2015

Table of contents

Installation declaration (for an incomplete machine).....	4
1 General.....	5
1.1 Introduction	5
1.2 Safety instructions and Warnings	5
1.3 Guarantee terms and conditions.....	6
2 Installation and connection	7
2.1 General information.....	7
2.2 Connection terminals.....	8
2.3 Electrical connection	9
2.3.1 Fixed RPM, optional with load distribution or for parallel operation with the mains	9
2.3.2 Variable RPM with external potentiometer	10
2.3.3 RPM adjustment via digital signal	10
2.3.4 Optional inputs.....	11
2.3.4.1 Idle	11
2.3.4.2 Gain	12
2.4 Current Limit Override	13
2.5 EGT Shutdown	13
3 Hardware use (Keypad).....	14
3.1 Accessing the functions.....	14
4 Installation of PC software	15
5 Software use	17
5.1 Start window.....	17
5.1.1 Speed Values	18
5.1.2 Options	18
5.1.3 Settings	19
5.1.4 Governor Values.....	20
5.1.5 Master and Slave Readings.....	21
5.1.6 Controller Values	22
5.1.7 Loading/saving settings	22
5.2 Parameters menu.....	23

5.2.1	General use	23
5.2.2	Parameters 1	23
5.2.3	Parameters 2	23
6	Dimensions	24
7	Starting the motor	24
7.1	Checking the parameter settings	24
7.2	Starting and motor tuning	25
7.3	Optimisation of dynamics settings (Tuning)	25
8	Configurable parameters, values in [] = factory settings	26
9	Correction system faults	28
9.1	Motor does not start	28
9.2	Motor does not run with the correct variable RPM	28
9.3	Overspeed during start process.....	29
9.4	Engine unstable	29
10	Technical Data	30
10.1	Performance.....	30
10.2	Surroundings.....	30
10.3	Input/output parameters	30
10.4	Norms/standards.....	30
10.5	Reliability.....	30
10.6	Mass and weight	30
10.7	Configuration parameters	31

Installation declaration (for an incomplete machine)

Installation declaration

(Directive 2006/42/EC, Appendix II B)

The manufacturer, Huegli-Tech AG, hereby declares that the incomplete machinery:

General description:

DDD100 complies with the basic health and safety requirements of machinery directive 2006/42/EC
Appendix I.

The special technical documents in compliance with Appendix VII part B have been produced.

The incomplete machine corresponds with the following other EC directives:

Low tension directive 2006/95/EC

The following harmonised norms were applied:

EN ISO 12100-1; EN ISO 12100-2; EN ISO 14121-1;

The special technical documents are transmitted in electronic form as required by individual state offices.

Operating the incomplete machine is not permitted until the incomplete machine is built into a machine that conforms to the provisions of the machinery directive and an EC conformity declaration in compliance with Appendix II A is provided.

1 General

1.1 Introduction

The DDD100 is a Digital Dual Driver Governor for controlling motor rotation speed on single engines that require dual fuel pumps or throttle body actuators. The governor features fast and precise reaction to load changes.

DDD100 utilizes feedback from the Master and Slave Actuators and also the EGT (Exhaust Gas Temperature) via thermocouple to achieve optimum fuel equalization in each cylinder bank. The feedback from the Actuators allows the DDD100 to know if there is any fuel supply imbalance to each of the cylinder banks. The EGT feedback provides an indication of the power produced from each cylinder, which further eliminates any possibility of fuel supply imbalance resulting from mechanical tolerances and friction. Any fuel imbalance will be compensated by the DDD100 intelligent software algorithm to ensure that fuel supplies to each cylinder banks are always identical and balanced.

A closed control circuit using two actuators (Master and Slave), two temperature sensors (Master and Slave) and magnetic RPM sensor can be operated for a large number of motors in both an isochronous and static fashion. High precision and robust construction makes it possible to use in the harshest motor use conditions.

The microcontroller design provides precise and user-specific performance and functionality. The DDD100 enables exact (<0.25%) isochronous rotation speed control. The permanent memory saves the settings even if the power supply is interrupted and thanks to a wide voltage range of 12-24VDC.

1.2 Safety instructions and Warnings

Before installing and starting the device, please read the operating instructions. These contain important notes for safety and use.

No liability can be accepted for damage arising from failure to follow the instructions or any inappropriate use.

The governor may only be used for the manner of operation prescribed in the operating instructions and only in connection with third-party devices and components recommended or installed by us or software supplied by us. Any other use shall be considered inappropriate use and will result in the voiding of all liability and warranty claims against the manufacturer.

Interventions and alterations that influence the safety technology and the functionality of the governor may be carried out only by the manufacturer. Fault-free and safe operation is conditional upon competent transport, assembly and installation as well as qualified use and correct maintenance.

All relevant accident prevention regulations and other generally recognised technical safety and health and safety at work rules are to be observed. Fault-free functioning of the machinery and its peripheral components is only guaranteed with original accessory parts and spare parts.

The DDD100 digital dual driver governor is robust enough to be placed in a control cabinet with other operating control devices or installed on the motor. If water, mist or condensation can come into contact with the controller, it should be mounted vertically, allowing the liquid to flow away from the controller. Extremes of heat should be avoided.

Overspeed protection



IMPORTANT


- An overspeed shut down mechanism must be installed separately from the control system as a safety measure, to prevent motor faults that may result in damage or injury to machinery or persons.
- A secondary shut down device (fuel valve) must be installed.

Safety protection



IMPORTANT

- Protective Earth (PE) must be connected with Battery Minus terminal always.



1.3 Guarantee terms and conditions

Correct use

The device is intended for exclusive use under the conditions described in the "Technical Data" rubric. Other uses are potentially dangerous. Huegli-Tech AG cannot accept liability for damage which results from incorrect use or application other than that for which it was intended.

Use of Accessories

Accessory parts may be installed or added only when they have been explicitly authorised by Huegli-Tech AG. Any claims under guarantee, warranty or product liability shall be void if other parts are used.


The general guarantee terms and conditions of Huegli-Tech AG shall apply.

2 Installation and connection

2.1 General information

The pickup cable should be shielded to guarantee that no electromagnetic interference can reach the engine speed governor. The shield should be on-side on the battery negative.

To maintain the correct distance between the flywheel and the RPM sensor, the sensor must be rotated in until the flywheel clicks and then rotated out again for $\frac{3}{4}$ of a rotation. This achieves the correct spacing between flywheel and sensor. To be able to start the motor, the RPM sensor must generate at least 1V AC RMS during the start.



Cross-section of the battery and actuator cable at terminals S, T, U, V, W and X: 1.5 mm² for 24 VDC or 2.5 mm² for 12 VDC

For longer cables (>5m) the cable cross-section is to be increased appropriately to keep the voltage drop low.

- Battery positive (+) input, connection V, should be fused 8 A.
- The governor should be installed such that the housing has a connection with the chassis of the control cabinet.
- The cable of the actuator must be shielded along its entire length.
- The cable of the magnetic engine speed sensor must be shielded along its entire length.
- The cable of the variable RPM speed input can be up to 5m long. For longer runs, a shielded cable must be used.
- The shielding must always be grounded such that it does not come into contact with the chassis of the machine. This is to prevent scatter signals from entering the governor and causing interference. The shield must be grounded at one end.

2.2 Connection terminals

Connection terminal	Description	Definition
A	FEED BACK1	Master Actuator position
B	GND	Ground/chassis
C	FEED BACK2	Slave Actuator position
D	+5VDC	Master and Slave actuator feedback supply
E	EXT SPEED	Load distribution / synchronisation
F	T/C 1-	Master engine temperature input (Thermo couple input+)
G	T/C 1+	Master temperature input (Thermo couple input-)
H	T/C 2-	Slave temperature input (Thermo couple input+)
I	T/C 2+	Slave temperature input (Thermo couple input-)
J	RTD	Cold junction temperature input +ve
K	RTD	Cold junction temperature input -ve
L	SPEED2	RPM2
M	SPEED3	RPM3
N	GND	Ground/chassis
O	GAIN	GAIN parameter set 1 or 2
P	IDLE	Idle speed selection
Q	CANH	CAN bus high
R	CANL	CAN bus low
S	S+	Master Actuator (Plus)
T	T-	Master Actuator (Minus)
U	U-	Battery (Minus)
V	V+	Battery (Plus)
W	W+	Slave Actuator (Plus)
X	X-	Slave Actuator (Minus)
Y	Y-	Pickup (Ground) (Mass)
Z	Z+	Pickup (Plus)

2.3 Electrical connection

The DDD100 has a range of different connection options for various applications. The following describes the applications and relevant connection configurations


2.3.1 Fixed RPM, optional with load distribution or for parallel operation with the mains

With this application, up to three fixed RPM speeds can be selected by wiring in inputs Speed 2(L) and Speed 3 (M). The RPM settings can be set using the *Speed Governor Setup* PC software.

The rule here is:

Switch Speed 2 open /Speed 3 open	Speed 1 active
Switch Speed 2 closed /Speed 3 open	Speed 2 active
Switch Speed 2 open/Speed 3 closed	Speed 3 active
Switch Speed 2 closed/Speed 3 closed	Speed 3 active


If a load distribution and/or synchronisation/load control (for parallel operation with the mains) is additionally required, this can be achieved by wiring in the input EXT SPEED. Here a signal of 0 – 10 V DC (zero point = 5 V) is required. The DDD100 works on a negative principle, i.e. if the input voltage is < 5 V the nominal speed rises, at a voltage of > 5 the nominal speed drops. The Sync/Load Sharing functions must be activated using the Speed Governor Setup software!



2.3.2 Variable RPM with external potentiometer

If the motor has to be run with a variable Speed setting, this can be achieved with an external potentiometer (10 kOhm). This is to be connected according to the following diagram.


The External Speed Trim function must be activated in the Speed Governor Setup software. In addition, the Speed Trim DS and Speed Trim FS parameters of the desired settings can also be set here. Example: If *Speed Trim DS* 1400 RPM and *Speed Trim FS* 1800 RPM are required, these settings can be achieved variably with the external potentiometer.



2.3.3 RPM adjustment via digital signal

If the speed setting is required to be set via a digital signal, this is also possible with the DDD100. This may for example be necessary during parallel operation with the mains if the motor control only delivers digital signals for synchronisation and/or load control. The Binary Speed Up-Down function in the Speed Governor Setup software must be activated. In such cases, the Speed1 value is set as standard RPM (Speed 2 and Speed 3 are inactive). The nominal speed can be altered using inputs Speed 2 = RPM + and Speed 3 = RPM -. The Speed Min and Speed Max parameters define the limits of the adjustable RPM. The *Bin Speed Rate* parameter sets the adjustment of the RPM in milliseconds.

If a value of 200ms is set here with closed contact Speed 2 and/or Speed 3, the nominal speed changes with a speed of 1 rpm per 200ms. If the contact is closed for only a second, the nominal speed changes by 5 rpm.




2.3.4 Optional inputs

2.3.4.1 Idle

If this contact is closed, the motor runs at the set idle speed.


2.3.4.2 Gain

The DDD100 has two parameter sets for the PID governor. If the contact is open, parameter set 1 is active, when the contact is closed, parameter set 2. For some applications it may be necessary to use other parameters in idle than under load.



2.4 Current Limit Override


This feature is to supply more fuel to the engine during loading to protect the engine from under speed.



Override feature will start to work if the engine needed more fuel to compensate the sudden change in load of Genset in that case actuator opened up to override Position for set override time period after that come back to normal position within Current limit set value.

2.5 EGT Shutdown

This feature is to shut down the engine when the difference between Master and Slave banks EGTs are exceed the set value(Max EGT diff).




- ➔ Enable EGT control
- ➔ Shutdown EGT difference

Enable these options and set the allowable EGT difference between Master and Slave bank value in Maximum EGT difference.

Set the allowable Maximum EGT difference time

3 Hardware use (Keypad)

The DDD100 has three menu buttons, with which all parameters can be set locally. The set values are indicated on the LED display. In normal operating mode, the RPM is indicated on the display.



3.1 Accessing the functions

In SETUP mode, the functions listed below can be accessed using the SETUP/SCROLL button. Press and hold SETUP&'+ ' button simultaneously for 5 seconds then enter the correct password after that press and hold SETUP&'+ ' button simultaneously for 3 seconds to validate the password and then Each press of the SETUP/SCROLL button makes the next menu active. The active menu is shown on the LED display for 2 seconds, after which the relevant value of this function appears.

Settings are changed with the arrow keys [+] [-] and raise/lower the value by 1. If the arrow keys [+] [-] are held down longer, the value increases at a greater rate.

Normal operating mode	0000	RPM	e.g. 1500 rpm
Password entry	PA5d	Password	e.g. 1234
SETUP/SCROLL button: 1x press	GAI/5020	P value*	e.g. 50.20
SETUP/SCROLL button: 2x press	Int/2192	I value*	e.g. 21.92
SETUP/SCROLL button: 3x press	Der/0700	D value*	e.g. 7.00
SETUP/SCROLL button: 4x press	Gear/0170	Number of teeth	e.g. 170 teeth
SETUP/SCROLL button: 5x press	cran/0500	Crankspeed	e.g. 500 rpm
SETUP/SCROLL button: 6x press	fura/3	Fuel ramp	e.g. 3 secs.
SETUP/SCROLL button: 7x press	spra/10	Speed ramp	e.g. 10 secs.
SETUP/SCROLL button: 8x press	stpo/0050	Start Position	e.g. 50 %
SETUP/SCROLL button: 9x press	ospd/2000	Overspeed	e.g. 2000 rpm
SETUP/SCROLL button: 10x press	0000	RPM display	e.g. 1500 rpm
+ button: 1x press	2000 → 2001	Increase value by 1	for all parameters
- button: 1x press	2000 → 1999	Reduce value by 1	for all parameters

*Display of the values is dependent on input G (Gain). If this is open, parameter set 1 (Gain 1, Int 1 and Der 1) is shown; if the input is closed, parameter set 2 (Gain 2, Int 2 and Der 2) is shown.


4 Installation of PC software

Operating system Windows XP or later


Installation of the software is carried out by running the *Speed Governor Setup_V1.x.x w FW4.exe* installer and/or *Speed Governor Setup_V1.x.x.exe*.

File *Speed Governor Setup_V1.6.0 w FW4.exe* may only be used if MS Framework 4.0 Full is not installed on your machine (Client Version is not sufficient).


Once the installer is running, this window will appear first



✓ click "Next" to continue and follow the instructions



Click Finish to complete the installation!!



Click from Desktop to start use of software!!

5 Software use

Before using the motor for the first time, the basic parameters of the DDD100 must be configured. The factory settings must be checked.




5.1 Start window

After the program has started, a screen appears in which several areas are shaded red. This means that the PC is not yet connected to the DDD100.

If the DDD100 was connected to the PC via a USB cable, a connection with the DDD100 will be created automatically. After the connection has been made successfully, the current DDD100 values will be displayed.

The program is closed by pressing the *Exit* button

The values displayed can now be altered by Click at the Setup menu -> Enable Configuration then key in the right password. Now all the parameters is enabled to accept the new values.




5.1.1 Speed Values

Speed 1:	First fixed RPM, input Speed 2 open/Speed 3 open
Speed 2:	Second fixed RPM, input Speed 2 closed/Speed 3 open
Speed 3:	Third fixed RPM, input Speed 2 open/Speed 3 closed
Speed Trim DS*:	Lowest RPM for external potentiometer
Speed Trim FS*:	Highest RPM for external potentiometer
Idle Speed:	Idle RPM, must be set to 600 – 700 rpm even if this function is not used; higher where required.
PID loop:	Interrogation cycle for PID governor

*only active when External Speed Trim not selected

5.1.2 Options

Gear Teeth:	Number of teeth on the flywheel. This parameter is used by the DDD100 to calculate the current RPM.
Fuel Ramp:	The start amount determines how long the actuator needs when starting the motor to reach the starting position.
Speed Ramp:	The speed ramp determines the time that the motor requires after starting to reach the nominal speed.
Crank Termination:	This value is used by the DDD100 to determine if the motor is starting or running. As soon as the motor RPM exceeds this limit, the governor switches from the start routine to PID regulation. As a guide value, an RPM of 200 – 300 rpm should be entered here. This value must be smaller than the IDLE SPEED.
Overspeed:	If the overspeed value is exceeded, the engine speed governor is switched off to cut the motor. The digital display of the DDD100 will show - - - -. After restarting, the current RPM will be shown again.
Start Position:	Position of the actuator when the motor starts. The actuator remains in this position as long as the Crank Termination value (starter cut-out) is not exceeded.
Current Limit:	This is the current limit of the actuator, so that under full load the actuator does not consume excessive amounts of electricity. The current limit should be set such that e.g. with a Current Limit of 80, the actuator still draws at full load. If this is not the case, the Current Limit must be increased.
Override time:	Time period to override the current limit setting during loading of the engine.
Synch/Load Sharing:	Activates analogue input for load distribution and/or a synchronisation/load control, see 2.3.1
Binary Speed Up/Down:	Activates digital mode for speed setting, see 2.3.3



When this mode is activated, the Speed Values are altered. The values for *Bin Speed Rate*, *Speed MIN* and *Speed MAX* can then be entered

- External Speed Trim: Speed setting by potentiometer, see 2.3.2
- Adjust Actuator Output: This function is only active when the motor is not running. If this function is activated, the Start Position value is transmitted directly to the actuator. A visual inspection can then determine how far the actuator actually moves during the start without having to actually start the motor.
- EGT control enable: Activates **Exhaust Gas Temperature** control.
- Position following: Activates the position PID for slave actuator to follow the Master actuator position.
- Shutdown EGT difference: Shuts down the engine If the EGT difference between Master and Slave bank exits the set value for set period.
- Enable override: Override the current limit setting for supplying more fuel during Loading up to set period (Override time).


5.1.3 Settings

- Master actuator offset: To adjust the displacement of Master actuator position. Set the displacement value as offset to get '0' as the start position.
- Slave actuator offset: To adjust the displacement of Slave actuator position. Set the displacement value as offset to get '0' as the start position.
- EGT master offset: To adjust the temperature readings of Master EGT. Set the difference of actual and measured value as offset to get actual temperature readings.
- EGT slave offset: To adjust the temperature readings of Slave EGT. Set the difference of actual and measured value as offset to get actual temperature readings.
- EGT Tolerance minimum: The minimum tolerance level for the set temperature. If the EGT control enable option is selected and slave temperature falls below this value (master – tolerance) then temperature balancing will start to work.
- EGT Tolerance maximum: The maximum tolerance level for the set temperature. If the EGT control enable option is selected and slave temperature rises above this value (master + tolerance) then temperature balancing will start to work.

- EGT control start: If the EGT control enable option is selected and actual temperature rises above this value then temperature compensation will get enable otherwise disabled.
- Max EGT difference: Master and Slave EGT difference acceptable limit.
- Max EGT diff time: Allowable time period for Master and Slave EGT difference.


5.1.4 Governor Values

Various values are represented both graphically and numerically in the start window and the Controller Values window.



*If the Synch./Load Sharing, Binary Speed Up Down or External Speed Trim function was activated, the value changes using the current Speed setting. This allows monitoring of whether the external signals are functioning without fault. This is especially helpful with the Synch/Load Sharing function to monitor the corresponding signal from the motor controls.

5.1.5 Master and Slave Readings



5.1.6 Controller Values

In client-specific DDD100 versions, all PID parameters are factory-set for the best motor operation characteristics. Depending on the individual dynamics of each motor, subsequent adjustments may be required.

For new applications, these parameters must be defined before starting the motor.

- Gain 1: P value parameter set 1 (input Gain (G) open)
- Int 1: I value parameter set 1 (input Gain (G) open)
- Der 1: D value parameter set 1 (input Gain (G) open)
- Gain 2: P value parameter set 2 (input Gain (G) closed)
- Int 2: I value parameter set 2 (input Gain (G) closed)
- Der 2: D value parameter set 2 (input Gain (G) closed)


These values cannot be altered in the start window!
The currently selected parameter set is highlighted green!

5.1.7 Loading/saving settings

The following functions are only available when the DDD100 is connected to the PC!

A configuration can be saved on the computer by clicking on the “Save Configuration Settings” menu.

If you wish to transfer a saved configuration to another DDD100, click on the “Load configuration settings” menu and select the desired configuration file. The configuration will then be loaded onto the DDD100.




A particular and very helpful function is offered by the Start Up Values button. If you have adjusted the governor and cannot reproduce the original values (and have not stored these) this function can be used to retrieve them. The PC software saves the settings that were stored at the time the connection was established with the DDD100.

5.2 Parameters menu

To open this window, Click “Master PID Configuration” tab.

The currently active parameter set is indicated in a green font. In the adjacent illustration, this is currently parameter set 1



5.2.1 General use

P, I and D parameters may be changed using the – and + arrow keys and the green bar when the motor is active or idle.

The motor RPM and the output signal are visible on the display.

You can return to the start window using the Exit button.

Action	Display	Description	Information
+ arrow key : 1x short press	1 0.0 → 1 0.1	Increase value by 0.1	for all P, I, D parameters
- arrow key : 1x short press	1 0.0 → 9.9	Decrease value by 0.1	for all P, I, D parameters
+ arrow key : 1x hold down	1 0.0 → 1 0.1	Continue to increase value by 0.1	for all P, I, D parameters
- arrow key : 1x hold down	1 0.0 → 9.9	Continue to decrease value by 0.1	for all P, I, D parameters
hold down green bar	2 3.7 → 2 3.7	Value remains unchanged	for all P, I, D parameters
hold down green bar and move	2 3.7 → 2 3.7	Value remains unchanged	for all P, I, D parameters
release green bar	2 3.7 → 4 1.8	Value changes	for all P, I, D parameters

5.2.2 Parameters 1

Gain 1: P value parameter set 1 (input Gain (G) open)

Int 1: I value parameter set 1 (input Gain (G) open)

Der 1: D value parameter set 1 (input Gain (G) open)


5.2.3 Parameters 2

Gain 2: P value parameter set 2 (input Gain (G) closed)

Int 2: I value parameter set 2 (input Gain (G) closed)

Der 2: D value parameter set 2 (input Gain (G) closed)

6 Dimensions



7 Starting the motor

7.1 Checking the parameter settings

Before starting the motor with the DDD100, follow this procedure:

- Switch on voltage, do not start motor.
- Check all the important parameters for correct values in SETUP mode:
Number of teeth, Overspeed, RPM settings, starter cut-out and start position.

7.2 Starting and motor tuning

The fuel supply to the motor is pre-set by the actuator according to the start FUEL parameter (default is maximum fuel supply). The speed ramp (Fuel Ramp) controls the rate at which fuel is increased to start the motor.

If the motor fails to run in a stable fashion after starting, set the GAIN, stability and Derivative with appropriate parameters until the motor is stable.

In client-specific DDD100 versions, all PID parameters are factory-set for the best motor operation characteristics. Depending on the individual dynamics of each motor, subsequent adjustments may be required.

In the case of devices which are not pre-set, these parameters must be entered before starting the motor.

GAIN: 10 %

INTEGRAL: 10 %

DERIVATIVE: 1 %

Activate starter.

The motor will run at the set idle RPM or nominal RPM. If instability is detected, reduce GAIN and INTEGRAL, and DERIVATIVE where required.

7.3 Optimisation of dynamics settings (Tuning)

Increase the GAIN by pressing the + button until the motor oscillates, then slowly ease back by pressing the – button until the motor runs smoothly. Set Integral in the same manner.

The reaction of the governor can be controlled with short manual taps of the actuator control. GAIN and INT are to be set to the shortest possible reaction times.

In some cases it can be necessary to adapt the speed compensation (DER) as well.

If the motor oscillates quickly, even if the GAIN is set low, the DER can be reduced by pressing the – button.

If the motor oscillates very slowly, the DER can be increased by pressing the + button.

8 Configurable parameters, values in [] = factory settings

Description	Term	Definition	Range
Speed 1	Fixed RPM 1	Speed setting 1, Input Speed 2 open, Speed 3 open	0 – Overspeed rpm [1500]
Speed 2	Fixed RPM 2	Speed setting 2, Input Speed 2 closed, Speed 3 open	0 – Overspeed rpm [1400]
Speed 3	Fixed RPM 3	Speed setting 3, Input Speed 2 open, Speed 3 closed	0 – Overspeed rpm [1300]
Speed Trim DS	RPM MIN	Minimum nominal speed when function <i>External Speed Trim</i> is activated	0 – (Speed Trim FS - 10) [1500]
Speed Trim FS	RPM MAX	Maximum nominal speed when function <i>External Speed Trim</i> is activated	0 – Overspeed rpm [1800]
Bin Speed Rate	P-proportion	Update time for nominal speed adjustment when function <i>Binary Speed Up Down</i> is activated	0 – 1500 ms [1300]
Speed MIN	RPM MIN	Minimum nominal speed when function <i>Binary Speed Up Down</i> is activated	0 – (Speed MAX -10) [1500]
Speed MAX	RPM MAX	Maximum nominal speed when function <i>Binary Speed Up Down</i> is activated	0 – Overspeed rpm [1800]
Idle Speed	idle	RPM of <i>motor</i> when idle input is closed	0 – 3000 rpm [700]
PID Loop	PID update	Update time of the PID governor	0 – 255 ms [10]
Gear Teeth	Number of teeth	Number of teeth on flywheel	50 – 255 [120]
Fuel Ramp	Fuel ramp	Time to reach start position after switching on motor	0 – 20, 0 = no ramp [1]
Speed Ramp	Speed ramp	Ramp from start to nominal speed	0 – 100, 0 = no ramp [3]
Crank Termination	Starter cut-out	RPM at which the DD100 switches from start mode to control mode	0 – 2000 rpm [200]
Overspeed	overspeed	Maximum RPM of the motor	0 – 4000 rpm [2000]
Start Position	Start Position	Position of actuator when switching on motor	0 – 100 % [50]
Current Limit	Current limit	Current limit for actuator	0 – 100 % [70]
Override Time	Current limit Override Time	Current limit override allowed for this period	0 – 999 seconds[5]
Override position	Override actuator position	Maximum override position allowed during current limit override	0 – 100% [100]
Gain 1	Proportional value 1	Parameter set 1 for Proportional value of the engine speed governor, input GAIN (G) open	0 – 100 % [50.0]
Int 1	Integral value 1	Parameter set 1 for Integral value of the engine speed governor, input GAIN (G) open	0 – 100 % [10.0]
Der 1	Differential value 1	Parameter set 1 for Differential value of the engine speed governor, input GAIN (G) open	0 – 100 % [40.0]
Gain 2	Proportional value 2	Parameter set 2 for Proportional value of the engine speed governor, input GAIN (G) closed	0 – 100 % [50.0]
Int 2	Integral value 2	Parameter set 2 for Integral value of the engine speed governor, input GAIN (G) closed	0 – 100 % [10.0]
Der 2	Differential value 2	Parameter set 2 for Differential value of the engine speed governor, input GAIN (G) closed	0 – 100 % [40.0]

Description	Term	Definition	Range
Gain for Slave Actuator	Proportional value	Parameter set for Proportional value of the slave actuator position	0 – 100 % [30.0]
Integrator For Slave Actuator	Integral value	Parameter set for Integral value of the slave actuator position	0 – 100 % [56.0]
Derivative For Slave Actuator	Differential value	Not used	0 – 100% [0]
Gain for Slave EGT	Proportional value	Parameter set for Proportional value of the slave actuator position	0 – 100 % [54.0]
Integrator For Slave EGT	Integral value	Parameter set for Integral value of the slave actuator position	0 – 100 % [40.0]
Derivative For Slave EGT	Differential value	Parameter set for Differential value of the slave actuator position	0 – 100 % [18.0]
Master Actuator offset	Position offset value	Set the master actuator displacement value as offset to get '0' as the start position.	0 – 100 % [0]
Slave Actuator offset	Position offset value	Set the slave actuator displacement value as offset to get '0' as the start position.	0 – 100 % [0]
Master EGT offset	Master exhaust gas temperature offset	Set the difference of actual and measured value as offset to get actual temperature readings.	-50 – 850 °c [0] [0]
Slave EGT offset	Slave exhaust gas temperature offset	Set the difference of actual and measured value as offset to get actual temperature readings.	-50 – 850 °c [0] [0]
EGT Tolerance minimum	EGT tolerance low	The minimum tolerance setting for the set temperature	0 - -100 °c [-5] [-5]
EGT Tolerance maximum	EGT tolerance high	The maximum tolerance setting for the set temperature	0 - +100 °c [5] [5]
EGT control start	EGT control enable temperature	The minimum temperature set to start the EGT control	0 - 850 °c [100] [100]
Max EGT diff	Maximum EGT difference	Maximum allowable EGT difference between Master and Slave Bank	0 - 850 °c [100] [50]
Max EGT diff time	Maximum EGT difference time	Maximum EGT difference between Master and Slave bank allowable period after that Engine will get shutdown If EGT shutdown enabled	0 - 900 seconds [60] [120]

9 Correction system faults

WARNING

Disconnect the connector cable to the actuator only when power is off.

9.1 Motor does not start

Fault, LED signal	Possible cause	Check	Action
No Display (unit dead)	Voltage too low	Check voltage between connection V(+) and U(-)	Adjust power supply and polarity (min.17 V for 24V system)
	Battery and wiring	Check battery voltage during start procedure; check wiring.	Voltage drop to large because of small cable cross-section or low battery.
Display shows 0000	No signal from magnetic RPM sensor.	Measurement of voltage between terminals Y and Z (during start-up)	Should be min. 1.0 VRMS during start-up
	Actuator fault	Check wiring. Measure voltage at terminals S and T for Master actuator W and X for slave actuator. Measure resistance.	See connection diagram. Note actuator specification. Do not separate cables when the actuator is under power!
	Fuel supply	Check fuel	Correct fuel supply

Fault, LED signal	Possible cause	Check	Action
Speed selection not working (Speed1,Speed2&Speed3)	Terminals L and M are not connected correctly.	Check wiring	If neither 'L' nor 'M' are connected, the DDD100 is configured for speed1
	Incorrect number of teeth	Check Gear teeth settings in PC software	Correct setting
	Incorrect Speed setting	Check settings in PC software	Correct setting




9.2 Motor does not run in External Speed Trim mode (Variable speed mode)

Fault	Possible cause	Check	Action
Motor does not run in External Speed Trim mode	Terminals M,N are not connected correctly to potentiometer	Check wiring.	See connection diagram
	Incorrect number of teeth	Check settings in PC software	Adjust setting
	Incorrect configuration	Check settings in PC software	Select External speed trim in PC software

9.3 Overspeed during start process

Fault, LED display	Possible cause	Check	Action
display - - - -	Overspeed limit value set too low	Check overspeed set value	Adjust value
	Tuning sub-optimal	Check PID set value	Increase GAIN, INT. and speed ramp where required.
	Starter cut-out set too high	Check start fuel %setting	Adjust value

9.4 Engine unstable

Fault, LED signal	Possible cause	Check	Action
Slow periodic vibration 	Friction on connection shaft or control rod	Check mechanical parts.	Remove friction
	Battery voltage too weak	Check battery and wiring: Min. 20V for 24V system	Replace battery, Adapt wiring
	Actuator too weak	Check Actuator	Use stronger actuator
	Too little speed compensation	Check PID setting	Increase DER
Fast periodic vibration 	GAIN too high		Reduce GAIN
	Too much speed compensation	Check PID setting	Reduce DER
	Fault in fuel supply	Check fuel supply	Remove fault in injection system
	Spongy or worn clutch	Check play in clutch	Correct fault
Governor is ok but actuator control (actuator lever) vibrates approx. 1 mm 	Rotary oscillation caused by spongy clutch or too much play in clutch		Correct fault
	Misfire of a cylinder		Correct fault

10 Technical Data

10.1 Performance

Isochronous/stability	±0.25%
RPM range	300 - 8 KHz (112-4000 RPM for flywheel with 160 teeth)
RPM variation with temperature	±0.25% max.
Idle adjustment	Full Range
Speed Trim	Programmable 0-100%, (default = 5%)

10.2 Surroundings

Temperature range	-40° to 85°C (-40 to +180°F)
Relative humidity	up to 95%
Surface finish	Fungus Proof and Corrosion Resistant
CE certificate	EN55011, EN61326-1

10.3 Input/output parameters

Supply voltage	12 or 24 VDC Battery, (6.5 VDC to 33 VDC)
Polarity	Negative Mass (housing insulated)
Current drain	60 mA max. continuous, plus actuator current
Max permitted actuator current	8 A continuous
Engine speed sensor signal	1 – 120 V RMS
Output (terminal x an DDD100)	up to 20 mA
Load Share/Synchronizer Input	0-10 VDC (5V nominal, reversed, 5 rpm/V)
Reverse Power Protection	Yes
Transient Voltage Protection	60V

10.4 Norms/standards

Authorising office	CE and RoHS requirements
Communication	SAE J1939 (Option)

10.5 Reliability

Vibration	7G, 20-100 Hz
Shock	20G Peak
Inspection	100% functionality inspection

10.6 Mass and weight

Dimensions	223 x 136 x 36 mm
Weight	1.000 kg
Installation	direct on motor chassis, preferably vertical, with rubber shock absorbers, insulated, or in control cabinet

10.7 Configuration parameters

Number of flywheel teeth, range.....	50 -250 teeth
Overspeed protection	4000 rpm
Starter cut-out speed	50 - 1000 Hz
Fixed RPM	400 – 8 000 Hz
Variable RPM.....	400 – 8 000 Hz
Prescribed start quantity.....	0 - 100 %
Start ramp	0 – 20 secs.
Speed ramp.....	0 - 100 secs.